

Manual, Assembly instruction: Brodit 853304

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the center console frame and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the angled edge on the left side of the ProClip into the gap between the stereo and the center console panel frame.
3. Press firmly forward on the right side of the ProClip so the angled edge on the right side snaps into the gap below the Gap Opener (Spaltöffner). Press on the right side of the ProClip, towards the stereo, to make sure the angled edge is all the way into the gap. Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.