

## Manual, Assembly instruction: Brodit 853319

Angled mount



**Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the panel frame surrounding the air vent and the padded part of the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Hold the ProClip in a 45-degree angle of the dashboard and press the curved edge on the right side of the ProClip into the gap above the gap opener. At the same time: flip the ProClip towards the air vent, while pressing the curved edge all the way into the gap. Pull out the gap opener.

3. Press the thin end of the enclosed gap opener into the gap between the panel frame surrounding the air vent and the center console panel, to widen the gap. Press firmly forward on the left side of the ProClip so the angled edge goes all the way into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.