

Manual, Assembly instruction: Brodit 853323

Center mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the climate control panel frame, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Hold the ProClip in a 45-degree angle of the dashboard and press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Flip the ProClip upwards, towards the air vent, and at the same time press the lower part of the ProClip all the way into the gap. Pull out the gap opener.

3. Press the thin end of the gap opener into the gap between the air vent frame and the dashboard, to widen the gap. Press the upper part of the ProClip upwards and forward so the angled edge hooks into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.