

Manual, Assembly instruction: Brodit 853331

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. 1a. Loosen the screw on the lower right side of the upper center panel a few turns. 1b. Remove the screw on the lower right side of the lower center panel.

2. Peel off the cover of the adhesive tape on the ProClip. Press the curved edge on the upper part of the ProClip, up behind the loosened panel and at the same time flip the lower part of the ProClip downwards.

3. Adjust the hole in the lower part of the ProClip to match over the hole in the center panel and screw in the removed screw.

4. The ProClip is in place.