

Manual, Assembly instruction: Brodit 853346

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the air vent and the padded part of the dashboard, to widen the gap. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

2. Press the gap opener into the gap between the panel surrounding the air vent and the padded part of the dashboard. Press forward on the upper part of the gap opener to expand the gap even more. Keep the gap opener in this position and press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press down on top of the left corner of the ProClip.

3. Press down on top the right corner of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.