

Manual, Assembly instruction: Brodit 853347

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the panel frame surrounding the stereo and the padded console edge to widen the gap. NOTE: The print on the one side of the gap openers has to point towards the steering wheel. Press firmly forward on the gap openers until the thin cut part is all the way into the gap. Clean the part of the panel between the gap openers with the enclosed alcohol pad. Peel off the cover of adhesive tape on the ProClip.

2. Place the ProClip between the gap openers. Press forward on the upper side of the ProClip so the corner of the grooved edge goes into the gap.

3. Press firmly forward on the lower side of the ProClip and at the same time: bend the ProClip towards the console edge. Press firmly until you see or hear/feel it snaps into place. Pull out the gap openers.

4. The ProClip is in place.