

## Manual, Assembly instruction: Brodit 853350

Angled mount, High



**Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the display/air vent and the dashboard to widen the gap.
2. Press the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
3. Press the gap opener into the gap between the display/air vent and the dashboard. Press forward on the upper part of the ProClip so the upper edge snaps into place in the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.