

Manual, Assembly instruction: Brodit 853351

Center mount May obstruct view of speedometer.



Attention! Please read all of the instructions before attaching the ProClip.

1. Peel off both adhesive tape covers on the ProClip. Hook the angled edge on the ProClip into the gap between the dashboard and the frame surrounding the air vent.
2. Pull the ProClip towards you/downwards. Hook the angled edge under the edge of the frame surrounding the air vent.
3. The ProClip is in place.
4. The ProClip is in place.