

Manual, Assembly instruction: Brodit 853352

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two part. Part 1. Attaching part. Part 2. ProClip face plate.

1. Peel off the cover of the adhesive tape on Part 1. Press the angled edge on Part 1 into the gap in the console.

3. Press the lower part towards the console so the angled edge hooks into the gap.

3. Open up the predrilled holes in Part 2. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.