

Manual, Assembly instruction: Brodit 853354

Angled mount, Low



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Place the ProClip over the control panel so the upper part could be pressed into the gap between the stereo and the surrounding panel, so far to the right as possible.

2. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener. Flip the upper part of the ProClip upwards so the curved edge hooks into the gap. Pull out the gap opener.

3. Press the gap opener into the gap between the stereo and the surrounding frame. Press the angled edge on the upper part of the ProClip into the gap, so far to the right as possible, next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.