Manual, Assembly instruction: Brodit 853357

Angled mount

1.)

2.)

3.)

4.)

Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding frame, to widen the gap. Peel off the cover of the adhesive tape on Part 1.

2. Press the angled edge on Part 1 into the gap below the gap opener. Press to the right on Part 1, away from the steering wheel, so the angled edge hooks behind the stereo and the adhesive attaches to the frame surrounding the stereo. Pull out the gap opener.

3. Open up the predrilled holes in Part 2 with a screwdriwer (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws. NOTE! Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.