

Manual, Assembly instruction: Brodit 853359

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the right side of the ProClip into the gap in the sidewall (see arrow in picture).

2. Place your hand on the right side of the ProClip and push it towards the stereo so the angled edge on the left side goes into the gap between the stereo and the center console panel frame. Press until you see or hear/feel it click into place. NOTE: the angled edge goes into the gap by the stereo (see arrow in picture).

3. Place your fingers against the left part of the ProClip and push forward to make sure the angled edge is all the way into the gap.

4. The ProClip is in place. This ProClip fits models with various stereo styles and models with or without factory navigation screen.