

Manual, Assembly instruction: Brodit 853360

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed anywhere within the width of the air vents. You can also attach two ProClips within the width of the air vents.

1. Press the grooved edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
2. Press the grooved edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
3. Press forward on the ProClip until you hear/feel it snaps into the gaps.
4. The ProClip is in place.