

Manual, Assembly instruction: Brodit 853361

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the ProClip into the hollow by the screw on the backside of the control panel.
2. Pull the ProClip rightwards and towards you and hook the angled edge over the edge of the control panel.
3. Hook the angled edge of the ProClip over the edge of the control panel.
4. The ProClip is in place.