

Manual, Assembly instruction: Brodit 853364

Center mount NOT for models with a compartment on top of the dashboard.

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the panel surrounding the display to widen the gap. Place the gap opener as far to the left as possible. Slide the gap opener 10-15 cm rightwards in the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Flip the ProClip downwards, towards the air vent, so the angled edge on the upper part of the ProClip hooks behind the panel surrounding the display. Pull out the gap opener.
3. Hook the lower part of the ProClip, with adhesive tape, under the upper edge of the air vent.
4. The ProClip is in place.