

Manual, Assembly instruction: Brodit 853369

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be attached anywhere within the width of the air vents.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the control panel to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Pull the upper part of the ProClip upwards and press it into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.