

Manual, Assembly instruction: Brodit 853370

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the frame surrounding the display to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.
2. Flip the ProClip upwards/forwards so the angled edge on the lower part hooks behind the frame surrounding the display. Press the upper and the lower part of the ProClip towards each other and hook the grooved edge on the upper part of the ProClip under the edge of the air vent housing.
3. Place your thumb inside the ProClip and press upwards, so the upper part hooks properly in place. Pull out the gap opener.
4. The ProClip is in place.