

Manual, Assembly instruction: Brodit 853372

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the THICK end of the enclosed gap opener into the gap between the air vent and the frame surrounding the control panel, to widen the gap. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the upper part of the ProClip into the gap between the air vent and the surrounding frame.
2. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap next to the ProClip, between the air vent and the surrounding frame. Press downwards on the angled upper edge of the ProClip so it goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.