

Manual, Assembly instruction: Brodit 853373

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Hook the left part of the ProClip, with adhesive tape, over the edge surrounding the control panel.
3. Press forwards on the right side of the ProClip so the angled edge on the right part of the ProClip hooks into the gap 1-2 cm above the gap opener. Press the angled edge towards the control panel so it goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.