

Manual, Assembly instruction: Brodit 853375

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. 1. Peel off the adhesive tape covers on the ProClip. Press the upper edge of the ProClip upwards into the gap between the panel surrounding the air vent and the dashboard. 2. Press the lower part of the ProClip upwards in the same time as you pull the center part of the ProClip towards you, bending the ProClip slightly. 3. Press the lower part of the ProClip into the gap between the stereo and the surrounding frame. Press forwards on the lower part of the ProClip until it stops, so it is properly in place. 4. The ProClip is in place.