

Manual, Assembly instruction: Brodit 853376

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel of the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the climate control panel and the surrounding frame so it hooks behind the frame.
2. Press the angled edge on the upper part of the ProClip downwards/forwards so it hooks into the gap between the climate control panel and the surrounding frame.
3. The ProClip is in place.
4. The ProClip is in place.