

Manual, Assembly instruction: Brodit 853377

Center mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the center console panel frame, to widen the gap.

2. Slide the gap opener, while inserted into the gap, up along the frame so it is horizontally aligned. Peel off the cover of adhesive tape on the ProClip. Hook/press the angled edge on the left side of the ProClip into the gap above the gap opener.

3. Place your hand over the face plate and push the ProClip firmly to the right so the angled edge on the right side snaps into the gap between the center console panel and the stereo/navigation screen. Press firmly forward on the right side of the ProClip to make sure the angled edge is all the way into the gap and the adhesive tape attaches the panel frame.

4. The ProClip is in place.