

Manual, Assembly instruction: Brodit 853381

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the display and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Hook the grooved edge on the upper part of the ProClip into the gap between the gap openers.

3. Pull the ProClip downwards and hook the angled edge on the lower part of the ProClip under the edge of the dashboard, as far to the left as possible. Pull out the gap openers.

4. The ProClip is in place.