

Manual, Assembly instruction: Brodit 853382

Center mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. Remove the screws on top of the dashboard. Place the ProClip on the dashboard so the holes match. Screw the ProClip onto the dashboard by using the enclosed screws. The ProClip is in place.