

Manual, Assembly instruction: Brodit 853383

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the wood grain panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the thick end of the gap opener into the gap between the wood grain panel and the dashboard overhang. Pull the dashboard overhang upwards to widen the gap more. In the same time: hook the grooved edge on the upper part of the ProClip over the wood grain panel. Pull out the gap opener. Press downwards on the dashboard overhang so the adhesive tape on top of the ProClip attaches.

4. The ProClip is in place.