

Manual, Assembly instruction: Brodit 853384

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE! Please be very careful when attaching the ProClip, so the fragile leather interior does not get damaged.

1. Press the thin ends of the enclosed gap openers into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the left part of the ProClip into the gap between the gap openers. Pull out the gap openers.
3. Press forwards on the right side of the ProClip until you hear/feel the right end of the ProClip snap into place in the gap between the dashboard and the frame surrounding the control panel.
4. The ProClip is in place.