

Manual, Assembly instruction: Brodit 853407

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the frame surrounding the compartment, in order to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the frame surrounding the air vent and the frame surrounding the control panel. Press the angled edge in the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press downwards on the upper part of the ProClip and upwards on the lower part of the ProClip so both ends go all the way into the gaps.

4. The ProClip is in place.