

Manual, Assembly instruction: Brodit 853408

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Open the glove compartment. Press the angled edge on the right part of the ProClip into the gap between the glove compartment and the dashboard.

2. Pull the ProClip towards the steering wheel, so the angled edge on the right part of the ProClip hooks behind the glove compartment.

3. Pull the ProClip towards you and hook the grooved edge in the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.

4. The ProClip is in place.