

## Manual, Assembly instruction: Brodit 853415

Angled mount, Low

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Peel off the cover of the adhesive tape on the ProClip. Place the ProClip over the edge of the console so it hooks around both sides of the console.
2. Press the ProClip downwards so the angled left part hooks under the edge of the console.
3. The ProClip is in place.
4. The ProClip is in place.