

Manual, Assembly instruction: Brodit 853417

Angled mount, Low

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts Part 1: Attaching part (the smallest part) Part 2: ProClip face plate

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the cover of the adhesive tape on Part 1. Press the angled edge on part 1 into the gap below the gap opener.

2. Press Part 1 away from the steering wheel so the angled edge hooks behind the control panel and the adhesive tape attaches. Pull out the gap opener.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape it to the left. Screw Part 2 onto Part 1 with the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.