

Manual, Assembly instruction: Brodit 853418

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Press the thin end of the enclosed gap opener into the gap between the dashboard and the handle bar attachment cover, to widen the gap. Press the thin end of the other enclosed gap opener into the gap between the dashboard and the handle bar attachment cover. Peel off the cover of the adhesive tape on the ProClip.

2. Hook the angled edge on the lower part of the ProClip under the curved part of the handle bar and pull the upper part of the ProClip upwards and over the curved part of the handle bar.

3. Press firmly forward on the ProClip so the angled edges go into the gap next to the gap openers. Press until you see or hear/feel the angled edges snap into place. Pull out the gap openers and close the glove compartment door.

4. The ProClip is in place.