

Manual, Assembly instruction: Brodit 853423

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the left end of the ProClip into the gap between the control panel and the surrounding frame.
2. Flip the right part of the ProClip towards the glove compartment so the curved edge on the left part of the ProClip hooks behind the control panel.
3. Hook the angled edge on the right part of the ProClip behind the sidewall of the control panel.
4. The ProClip is in place.