

Manual, Assembly instruction: Brodit 853424

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the control panel and the surrounding frame, to widen the gap. Place the gap openers about 10 cm apart. Peel off the adhesive tape covers on the ProClip. Place the ProClip over the frame surrounding the control panel so the left part is between the gap openers and the long right part goes into the gap between the glove compartment and the frame surrounding the control panel.

2. Press the left part of the ProClip into the gap between the gap openers.

3. Press forwards on the ProClip so it goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.