

Manual, Assembly instruction: Brodit 853435

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Press the curved edge on the right end of the ProClip into the gap above the gap opener. Flip the left side of the ProClip towards the dashboard so the curved edge on the right part hooks behind the frame surrounding the control panel. Pull out the gap opener.

3. Press the gap opener into the gap in the frame surrounding the instrument panel. Hook the angled edge on the left part of the ProClip into the gap below the gap opener. Press the angled edge all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.