

Manual, Assembly instruction: Brodit 853438

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the exact same position as shown in the pictures.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the stereo, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the thin end on the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.
3. Press forwards on the right side of the ProClip so the adhesive tape attaches.
4. The ProClip is in place.