

Manual, Assembly instruction: Brodit 853440

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the display and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Place the ProClip by the display and press the curved upper edge forwards/upwards into the gap next to the gap opener.

2. Press forwards on the lower part of the ProClip so the thin end snaps into the gap between the frame surrounding the display and the control panel.

3. Press downwards on top of the ProClip so the lower part goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.