

## Manual, Assembly instruction: Brodit 853441

Angled mount



**Please read all instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tapes on the ProClip.
2. Press the left part of the ProClip into the gap between the stereo and the surrounding frame.
3. Press forwards on the right side of the ProClip so the angled edge snaps into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.