

Manual, Assembly instruction: Brodit 853456

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the gap openers into the gap between the air vent panel frame and the padded dashboard edge, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Press the curved edge on the right side of the ProClip into the gap between the gap openers.

3. Flip the left part of the ProClip towards the instrument window so the curved edge on the right side hooks behind the air vent panel frame. Pull out the gap openers. Press the ProClip firmly towards the padded part of the dashboard and at the same time press forward on the ProClip face plate so the grooved edge on the left side of the ProClip goes into the gap between the padded part of the dashboard and the instrument window. Press until you see or hear/feel it snaps into place.

4. The ProClip is in place