

Manual, Assembly instruction: Brodit 853462

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding frame, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the angled edge on the left side of the ProClip into the gap between the stereo and the surrounding frame. Pull out the gap opener.
3. Press the gap opener into the gap between the control panel and the padded part of the dashboard. Press firmly forward on the right side of the ProClip so the angled edge on the right side goes all the way into the gap below the gap opener. Pull out the gap opener.
4. The ProClip is in place.