

Manual, Assembly instruction: Brodit 853477

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed Gap Opener (Spaltöffner)s into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Place the Gap Opener (Spaltöffner)s about 10 cm apart. Peel off the adhesive tape covers on the ProClip.
2. Press the left part of the ProClip into the gap between the Gap Opener (Spaltöffner)s. Pull out the Gap Opener (Spaltöffner)s.
3. Press the ProClip parts together, and place the right part into the air vent. Release the pressure slowly so the adhesive tape on the right part attaches to the inner wall of the air vent.
4. The ProClip is in place.