

Manual, Assembly instruction: Brodit 853478

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open both glove compartments. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the glove compartment and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the upper part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Flip the ProClip downwards so the angled upper edge hooks behind the frame surrounding the glove compartment.
3. Hook the lower part of the ProClip under the dashboard. Pull out the Gap Opener (Spaltöffner). Close the glove compartments.
4. The ProClip is in place.