

Manual, Assembly instruction: Brodit 853480

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the upper edge of the grooved part of the ProClip into the gap below the Gap Opener (Spaltöffner).
3. Press the lower edge of the grooved part of the ProClip into the gap. Press forwards on the ProClip so it goes all the way into the gap. Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.