

Manual, Assembly instruction: Brodit 853483

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Hook the lower part of the ProClip, with adhesive tape, into the air vent.
2. Pull the ProClip upwards and press the upper grooved edge into the gap between the frame surrounding the display and the dashboard overhang.
3. Press forwards on the upper part of the ProClip until you hear + feel it snaps into place.
4. The ProClip is in place.