

## Manual, Assembly instruction: Brodit 853485

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Peel off the adhesive tape covers on the ProClip. Press the lower part of the ProClip into the gap between the climate control panel and the surrounding frame. **2** Pull the upper part of the ProClip upwards and hook the upper edge into the lower part of the air vent.

**3.** Press downwards on top of the ProClip so the adhesive tape attaches.

**4.** The ProClip is in place.