

Manual, Assembly instruction: Brodit 853486

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the right end of the ProClip into the air vent housing, to the right of the air vent.
2. Press the left end of the ProClip rightwards and hook it inside the air vent housing.
3. Press forwards on the left part of the ProClip so it goes into the air vent housing.
4. The ProClip is in place.