

Manual, Assembly instruction: Brodit 853487

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the right part of the ProClip into the gap above the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Hook/Press the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.
4. The ProClip is in place.