

Manual, Assembly instruction: Brodit 853488

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the right part of the ProClip into the gap between the frame surrounding the display and the surrounding panel.
3. Press forwards on the left side of the ProClip so it goes into the gap below the gap opener. Pull out the gap opener.
4. The ProClip is in place.