

Manual, Assembly instruction: Brodit 853491

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the control panel, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.
2. Press forwards on the upper part of the ProClip so the angled lower edge hooks behind the control panel. Pull out the gap opener.
3. Hook the grooved edge on the upper part of the ProClip into the lower edge of the air vent.
4. The ProClip is in place.