

Manual, Assembly instruction: Brodit 853492

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the correct position, as shown in the pictures.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Open the glove compartment. Peel off the cover of the adhesive tape on the ProClip. Press the long right part of the ProClip into the gap between the glove compartment and the dashboard.

2. Pull the ProClip towards you, towards the steering wheel, so the angled edge on the right part hooks behind the glove compartment. Hook the left part of the ProClip, with adhesive tape, into the gap below the gap opener.

3. Press forwards on the left side of the ProClip so it goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.