

Manual, Assembly instruction: Brodit 853493

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1.Loosen the screw to the right under the dashboard overhang above the instrument window. Peel off the cover of the adhesive tape on the ProClip.

2. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Place the ProClip above the gap between the control panel and the dashboard. Press forwards on the gap opener so the gap is widened, in the same time press the lower right corner of the ProClip into the gap. Press the ProClip about 5 cm downwards in the gap. Pull out the gap opener.

3. Take a hold of the dashboard overhang above the instrument window and pull it towards you so the gap on top of the dashboard is widened. In the same time: press the ProClip downwards in the gap and pull the left side of the ProClip towards you so the angled left edge goes into the gap between the dashboard overhang and the dashboard. Tighten the screw.

4. The ProClip is in place.